

**TSE 3003**



Made in Germany  
[www.burg-waechter.de](http://www.burg-waechter.de)

**Operating instructions – Lite Mode**

**SecuTronic**



## TSE 3003 • Operating instructions – Lite Mode • SecuTronic



### **To open:**

Press the ON/Enter key.  
Enter your 6-figure code (works setting: 123456).  
Turn knob.

### **Changing the code:**

Press the ON/Enter key.  
Press the function key.  
Press the ON/Enter key twice.  
Enter your old 6-figure code.  
Press the ON/Enter key.  
Enter your new 6-figure code. Press the ON/Enter key.  
Enter your new 6-figure code again. Press the ON/Enter key.  
When display shows "Code change completed", press the function key.  
If the display shows "Code wrong or entry error", start again – the old code is still valid.

### **Info:**

Be sure to note the code and try several times with the door open!!!  
Blocking times for wrong input: 1 to 20 minutes.

### **Changing the language:**

Press the ON/Enter key.  
Press the function key.  
Press the "2" key.  
Press the ON/Enter key.  
Select the language you require using the "1" and "2" keys.  
Press the ON/Enter key.  
Press the function key.

### **Battery change:**

Data which has been saved is retained in the event of a power failure.  
Open the lid (see photos on cover).  
Insert 3 new batteries – **type LR6**.  
Dispose of old batteries in an environmentally friendly manner.

### **Standard Mode TSE / Professional Mode Safes:**

Please see the attached CD for information in this respect.  
Standard functions: Additional users, date & time, code length changes, protocol function...  
Possible additional functions with TSE: Opening delay\*, week time switch\*, public holiday / vacation calendar\*...  
(\*: standard with safes)



## **Burg-Wächter KG**

Altenhofer Weg 15

D - 58300 Wetter

Germany

[www.burg-waechter.de](http://www.burg-waechter.de)

[info@burg-waechter.de](mailto:info@burg-waechter.de)

Omissions and changes reserved  
Irrtum und Änderungen vorbehalten  
Sous réserve de fautes d'erreurs et de modifications  
Errores y modificaciones reservadas  
Errori e cambiamenti riservati  
Fouten en wijzigingen voorbehouden

BA/K TSE/TRS E8 HJW 02/2005